# Tutorial 5: Modify Object Properties and Layers in AutoCAD 2011

Audience: Users new to AutoCAD Prerequisites: None Time to complete: 15 minutes

# **In This Tutorial**

In this tutorial, you learn to:

- Modify the properties of objects
- Organize drawings with layers
- Modify object properties by changing layer properties

**NOTE** For more information on the topics covered in this tutorial, see the *AutoCAD User's Guide*.

### **Tutorial Files**

Download the tutorial files as follows:

1 Download the *modify\_objects.zip* from *http://www.autodesk.com/autocad-tutorials*.

2 Unzip modify\_objects.zip to C:\My Documents\Tutorials.

### **Lesson 1: Modify Object Properties**

In this lesson, you learn to modify object properties.

You can organize most of the objects in your drawing and control how they are displayed and plotted by changing their general properties, which include layer, linetype, color, lineweight, and plot style. Other properties are object-specific; for example, the properties of a circle include radius and area, and the properties of a line include length and angle.

You can change object properties in your drawing with the Properties or Quick Properties palettes.

#### To display the properties of objects

Click Start menu (Windows) ➤ (All) Programs ➤ AutoCAD
 2011 ➤ AutoCAD 2011-English.



**3** In the Select File dialog box, browse to C:\My Documents\Tutorials and select the file objects.dwg. Click Open.



- **4** Check the status bar to make sure you are in the 2D Drafting & Annotation workspace and the Show/Hide icon is turned on.
- 2 | Tutorial 5: Modify Object Properties and Layers in AutoCAD 2011

**5** In the drawing area, select the rectangle by clicking it.



**6** With the rectangle selected, on the ribbon, click View tab  $\blacktriangleright$  Palettes

panel > Properties.

The Properties palette displays the properties of the selected rectangle.

- **7** In the Properties palette, specify the following:
  - Color: **Red**

#### ■ Lineweight: **0.70 mm**

The thickness of the rectangle is increased by 0.70 mm.



Similarly, you can change other properties of the rectangle from the Properties palette.

8 Press Esc to deselect all selected objects.

Lesson 1: Modify Object Properties | 3

### To change the properties of a circle

 Before changing the properties of the circle, you must first load a linetype. Click Home tab ➤ Properties panel ➤ Linetype.



- 2 In the Linetype drop-down list, click Other. Then, in the Linetype Manager dialog box, click Load.
- 3 In the Load or Reload dialog box, select the DOT linetype. Click OK.
- 4 Click OK.
- **5** Select the circle by clicking it.



6 If the Properties palette is not displayed, then on the ribbon, click View

tab  $\blacktriangleright$  Palettes panel  $\blacktriangleright$  Properties.

The Properties palette displays the properties of the selected circle.

- 7 In the Properties palette, do the following:
  - Under the Geometry category, select Radius and enter **3** to replace the current value.
- 4 | Tutorial 5: Modify Object Properties and Layers in AutoCAD 2011

The radius of the circle changes to the value you entered.



 Under the General category, select Linetype and select DOT from the drop-down list.

The circle is now displayed with the DOT linetype.



You can change other properties of the circle from the Properties palette.

In this lesson, you learned how to change the properties of a rectangle and circle using the Properties palette.

Lesson 1: Modify Object Properties | 5

# Lesson 2: Organize Drawings with Layers

In this lesson, you learn to create layers and to control the visibility of objects in the drawing.

Layers are like transparent overlays on which you organize and group different kinds of drawing objects. The objects you create have common properties which include colors, linetypes, and lineweights. An object can inherit these properties from the layer it is drawn or placed on, or properties can be specifically assigned to individual objects.

You can group objects with similar properties together on to a layer. This allows you to modify and manage multiple objects in your drawing from one central point. Changing the property for a layer, will update the property for all objects on the layer.

#### To create a new layer



- 2 In the Select Template dialog box, select *acad.dwt* and click Open.
- 3 On the ribbon, click Home tab ➤ Layers panel ➤ Layer Properties.

The Layer Properties Manager palette is displayed.

× ⊧	Current layer: 0												
	»	Status	Name	On	Freeze	Lock	Color	Linetype	Lineweight	Plot Style	Plot	New VP Freeze	Description
uañeu							-			-			
roperues inid													
	»	1		I									

For ease of use, you can dock the Layer Properties Manager. Click the Properties button on the title bar and click Anchor Left or Anchor Right.

6 | Tutorial 5: Modify Object Properties and Layers in AutoCAD 2011



**4** On the Layer Properties Manager, click the New Layer button.

육 🕏 | 율 🛃 😽 🖌 🗸

A new layer named Layer1 is automatically added to the layer list.

- 5 In the in-place editor, enter **Green Gas** as the new layer name by overwriting the default highlighted layer name.
- **6** In the Color column of the Green Gas layer, click White. In the Select Color dialog box, Index Color tab, click the Green color swatch and click OK.



Lesson 2: Organize Drawings with Layers | 7

- 7 In the Linetype column of the Green Gas layer, click Continuous. In the Select Linetype dialog box, click Load.
- **8** In the Load or Reload Linetypes dialog box, Available Linetypes list, select GAS\_LINE and click OK.

📤 Load or Reload Lin	etypes 💌
File acad.	in
Available Linetypes	
Linetype	Description
DOTX2	Dot (2x)
FENCELINE1	Fenceline circle0000
FENCELINE2	Fenceline square[][][][]
GAS_LINE	Gas lineGASGASGASGASGAS
HIDDEN	Hidden
HIDDEN2	Hidden (.5x)
HIDDENX2	Hidden (2x)
•	4
0	K Cancel Help

- **9** In the Select Linetype dialog box, Loaded Linetypes list, select the GAS\_LINE and click OK.
- **10** In the Lineweight column of the Green Gas layer, click Default. In the Lineweight dialog box, Lineweights list, select 1.00 mm and click OK.

📤 Lineweight	?
Lineweights:	
0.30 mm	*
0.35 mm	
0.40 mm	
0.50 mm	
0.53 mm	
0.60 mm	=
0.70 mm	=
0.80 mm	
0.90 mm	
1.00 mm	
1.06 mm	-
Original: Default	
New: 1.00 mm	
OK Cancel	Help

**11** Click the Set Current button.

4 B 🛱 🖢 😽 🗙 🖌

8 | Tutorial 5: Modify Object Properties and Layers in AutoCAD 2011

The Green Gas layer is now active. Objects that you draw, with this layer active, will inherit the properties as you have defined them.

12 On the ribbon, click Home tab ➤ Draw panel ➤ Line. Specify two points in the drawing area to create the line and press Enter to end the command.



You should see that the line is in green with the GAS\_LINE linetype and a thickness of 1.00 mm.

**TIP** To display the lineweights in your drawing, on the status bar, click Show/Hide Lineweight.

You have drawn a line on the Green Gas layer. All other objects you draw on this layer will inherit the layer properties. To add more layers, follow the same procedure and modify the color, linetype, lineweight properties as needed.

To help identify what each layer in your drawing is used for, you can provide a description in the Description column of the Layer Properties Manager.

c £	Cur £∯	rent layer: Green Gas : gas line in the house Search for layer												layer 🔍
	»	Status	Name 0	On 9	Freeze	Lock	Color white	Linetype Continuous	Lineweight — Default	Plot Style Color_7	Plot	New VP Freeze	Description	
	»	<ul> <li>All: 21</li> </ul>	Green Gas ayers displa	Ved of	2 total la	yers	green	GAS_LINE	1.00 mm	Color_3	8	E.	gas line in the house	

When you are working on complex drawings, your drawing can get crowded. Turning off a layer hides all objects in that layer from view. This way you can concentrate on the layer you are working on.

### To control the visibility of objects by turning off and turn on layers

- Ensure that the Layer Properties Manager is open. If the Layer Properties panel is not open, on the ribbon, click Home tab ➤ Layers panel ➤ Layer Properties.
- 2 On the Layer Properties Manager, select the Green Gas layer and click the light bulb in the On column. If the light bulb is yellow, the layer is turned on. 9

Clicking the light bulb toggles the layer on and off. When the layer is turned off, you do not see the objects on the layer.

In this lesson, you learned to create layers, assign properties to layers, and control the visibility of objects using layers.

# Lesson 3: Modify Object Properties by Layers

In this lesson, you learn to change the default and assigned properties of a layer. You change the color, linetype, and lineweight of layers.

#### To change the linetype assigned to a layer

- 1 Ensure that the Layer Properties Manager is open. Click in the Linetype column of the Green Gas layer.
- **2** In the Select Linetype dialog box, select a linetype from the listed options. If the linetype you need is not listed, click Load.



- **3** Select the HOT\_WATER\_SUPPLY linetype and click OK. The selected linetype is loaded.
- 10 | Tutorial 5: Modify Object Properties and Layers in AutoCAD 2011

Select Linetype		
Loaded linetypes		
Linetype	Appearance	Description
Continuous		- Solid line
GAS_LINE	aus aus aus-	- Gas lineGASGASGAS
HOT_WATER_SUPPLY	— + <b>w</b> - + <b>w</b> - + <b>w</b>	Hot water supply HW HW
•	III	Þ
ОК	Cancel	ad Help

4 Select the HOT\_WATER\_SUPPLY and click OK. Objects on the layer are updated to the HOT\_WATER\_SUPPLY linetype.



You have learned to change the linetype for a layer.

To change the color assigned to a layer

1 Ensure that the Layer Properties Manager is open. Click in the Color column of the Green Gas layer.

📤 Select Color			×
Index Color	True Color	Color Books	]
AutoCAD Color In	dex (ACI):		
		Bul auer	BuBlock
		DyEdyci	Dyblock
Color:			
10			
L			
	ОК	Cancel	<u>H</u> elp

Lesson 3: Modify Object Properties by Layers | 11

2 In the Select Color dialog box, the Index Color tab, select the Red color swatch and click OK. The object in the layer is updated to red color. Objects on the layer are updated to the color red.



You have learned to change the color for a layer.

#### To change the lineweight of a layer

- 1 Ensure that the Layer Properties Manager is open. Click in the Lineweight column of the Green Gas layer.
- **2** In the Lineweight dialog box, Lineweight list, select the lineweight 0.70 mm and click OK.

🖀 Lineweight	? 💌
Lineweights:	
0.25 mm	*
0.30 mm	
0.35 mm	
0.40 mm	
0.50 mm	
0.53 mm	=
0.60 mm	-
0.70 mm	
0.80 mm	
0.90 mm	
1.00 mm	*
Original: 1.00 mm	
New: 0.70 mm	
Hom. C.romin	
UK Cancel	Help

Objects on the layer are updated to the lineweight 0.70 mm.

You have learned to change the lineweight of a layer. In this lesson, you learned to modify the properties for a layer.

### 12 | Tutorial 5: Modify Object Properties and Layers in AutoCAD 2011